



ROOF

Application Instructions

TOOLS NEEDED

- Sprayer - Recommended - Chapin Pro Series, Backpack 4 gallon.
- Leaf Blower

PRIOR TO INSTALL

1. The roof needs to pass a pre-install inspection before application.
2. Once approved, make sure to secure plastic over windows and any glass or metal to protect from material splatter during the install.

APPLICATION

MAXSHIELD™ may be applied to new roofs or at any point thereafter.

1. Surface needs to be free of any substance that may interfere with penetration—including dirt, dust, or other contaminants. Blowing the surface with a leaf blower will remove any excess dust or debris before application.
2. Using a HVLP, pump-up, airless, backpack, or mechanical sprayer, apply MAXSHIELD™ at 300-350 sq/ft per gallon, maintaining a consistent, even spray.
3. Make sure the sprayer tip has been adjusted to allow for a fan spray. You do not want to have the material sprayed in a stream.
4. The entire surface **MUST** remain wet with MAXSHIELD™ for 10 minutes to allow the material to react properly with the surface. **DO NOT LET ANY AREA DRY OUT** - apply more MAXSHIELD™ if necessary to keep the surface wet - **DO NOT USE WATER**. After the wet material has reacted with the surface for 10 minutes, allow material to dry.

AFTER COMPLETION

1. The material can be left in the sprayers if another application will happen 2-3 days after initial use. If it is longer, empty excess material back into its original container and clean sprayer with warm water to prepare for the next application.