



CONCRETE

Application Instructions

TOOLS NEEDED

- Sprayer - Recommended - Chapin Pro Series, Backpack 4 gallon. Each material will need its own sprayer
- Broom - Medium Brissel
- Leaf Blower

HARDENER

MAXGUARD™ & MAXGUARD+™ may be applied to new concrete immediately after final trowel or at any point thereafter.

1. Surface needs to free of any substance that may interfere with penetration—including oils, dirt, dust, or other contaminants. If surface washing and scrubbing is necessary before application allow surface to dry completely before application.
2. If washing or scrubbing is not necessary, sweeping and blowing the surface with a leaf blower will remove any excess dust or debris before application.
3. Using a HVLP, pump-up, airless, backpack, or mechanical sprayer, apply MAXGUARD™ or MAXGUARD+™ at 300-350 sq/ft per gallon, maintaining a consistent, even spray, lightly broom out material immediately after spraying to help with consistent coverage.
4. Make sure the sprayer tip has been adjusted to allow for a fan spray. You do not want to have the material sprayed in a stream.
5. The entire surface MUST remain wet with MAXGUARD™ or MAXGUARD+™ for 10 minutes to allow the material to react properly with the surface. DO NOT LET ANY AREA DRY OUT - apply more MAXGUARD™ or MAXGUARD+™ if necessary to keep the surface wet - DO NOT USE WATER. After the wet material has reacted with the surface for 10 minutes, allow material to dry.



CONCRETE

Application Instructions

TOOLS NEEDED

- Sprayer - Recommended - Chapin Pro Series, Backpack 4gal. Each material will need its own sprayer
- Broom - Medium Brissel
- Leaf Blower

SEALER

MAXSEAL™ may be applied to new concrete after a 14 day cure period or anytime to existing concrete. MAXSEAL™ can also be applied to concrete after application of hardener, MAXGUARD™ or MAXGUARD+™. Allow the hardener to dry completely before application.

1. Once MAXGUARD+™ is dry apply MAXSEAL™ at 300-400 sq. ft. per gallon depending upon surface porosity.
2. Make sure the sprayer tip has been adjusted to allow for a fan spray. You do not want to have the material sprayed in a stream.
3. The entire surface MUST remain wet with MAXSEAL™ for 10 minutes to allow the material to react properly with the surface. DO NOT LET ANY AREA DRY OUT - apply more MAXSEAL™ if necessary to keep the surface wet - DO NOT USE WATER. After the wet material has reacted with the surface for 10 minutes, allow material to dry.
4. Allow surface to dry for 2 hours before using surface. For best results up to 8 hours is recommended.

AFTER COMPLETION

1. The material can be left in the sprayers if another application will happen 2-3 days after initial use. If it is longer, Empty excess material back into its original container and clean sprayer with warm water to prepare for the next application.
2. Rinse bristles of the broom with warm water to remove any excess material left over, if broom is not cleaned after the bristles will harden and not be able to be used again.